




Kit 1580

NISSAN Altima, 4-dr Sedan, *02–


***North America**



754 Rapid System
480R Rapid Traverse (North America)



480 Traverse (North America)



THULE[®]
SWEDEN

ISO 11154-E

The diagram illustrates the importance of instructions. It features a box on the left labeled 'THULE' with a warning symbol (a triangle with an exclamation mark) and a plus sign next to it. To the right of the plus sign is a box labeled 'instructions' with a warning symbol and the text 'Kit XXXX'. A person is shown reading the instructions.

754 Rapid System

480R Rapid Traverse (North America)

x1

x4

x4

x4

x1

x4

x4

480 Traverse (North America)




Europe		North America	
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
</			

Diagram showing the assembly of the base plate. It includes a perspective view of the base plate being assembled onto the bottom of the cabinet. Below this, three parts are listed:

- Part 539 (corner bracket) x 4
- Part 271 (longitudinal bracket) x 4
- Control panel (with buttons RR, FR, FL, RL) x 1



1





2





754 Rapid System
480R Rapid Traverse
(North America)



x4





x4



x4




480 Traverse
(North America)




x4

3



754 Rapid System




X

NISSAN Altima, 4-dr Sedan, *02–

X

34




Y

NISSAN Altima, 4-dr Sedan, *02–

Y

31,5

3



480R Rapid Traverse




480 Traverse



(North America)



X inch/mm



NISSAN Altima, 4-dr Sedan, *02–

X inch

X mm

38 ³/₄ "

984 mm



Y inch/mm



NISSAN Altima, 4-dr Sedan, *02–


Y inch

Y mm

37 ⁷/₈ "



962 mm

4




5


NISSAN Altima, 4-dr Sedan, *02--




6





i





A




B



	X mm	Y mm	X inch	Y inch
NISSAN Altima, 4-dr Sedan, *02-	255 mm	710 mm	10"	28"



7



GB/US	Tighten alternately
D	Die Schrauben abwechselnd anziehen
F	Serrer alternativement chaque côté
NL	Afwisselend aan de linker- en de rechterkant aandraaien
I	Alternare il serraggio delle viti
E	Apretar alternativamente
PT	Aperte alternadamente
S	Dra åt växelvis
FIN	Kierrä vuorotellen
EST	Pinguldage vaheldumisi
LAT	Pielvelciet pamišus
LIT	Užsukinėkite pakaitomis
PL	Śruby dokręcaj naprzemiennie
RU	Затягивайте попеременно





CZ	Pokrétla bagażníka dokręcaj dokręcaj naprzemiennie.
SK	Dofahujte striedavo
SLO	Privijajte izmenično.
HR	Naizmjenočno zategnite
HU	Egyarástól fűggetlenül szorítandó
GR	Σφιγγετε εναλλάξ
TR	Dönüşümlü sıkın

中文 交替拧紧



한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ





≈ 3 Nm





8



x1
17 mm





THULE SWEDEN ONE KEY SYSTEM		544 (x4) 596 (x6) 588 (x8) NA 510 (x10) EUR 452 (x12) ASIA